



ARCONIC
Innovation, engineered.

Instruction Manual
256BT
Pneudraulic Installation Tool

Patent Pending



Declaration of Conformity
2

Safety Instructions
3

Specifications
4

Principle of Operation
4

Operating Instructions
5

Measuring Tool Stroke
5

Maintenance
6

Disassembly Procedure
7-8

Assembly Procedure
9-10

Fill and Bleed
11-12

**Components Drawings
and Parts Lists**
13-15

Troubleshooting
16

Kits and Accessories
16

September 19, 2017
HK1109

Makers of Huck®, Marson®, Recoil®
Brand Fasteners, Tools & Accessories

**ARCONIC**

EC Declaration of Conformity

Manufacturer:

Huck International, LLC, Industrial Products Group, 1 Corporate Drive, Kingston, NY, 12401, USA

Description of Machinery:

Models 24#, 25#, and 2047 pneudraulic installation tools and specials based on their design (e.g. PR#####).

Relevant provisions complied with:

Council Directive related to Machinery (2006/42/EC)

British Standard related to hand held, non-electric power tools (ISO 11148-1:2011)

European Representative:

Rob Pattenden, Huck International, Ltd. Unit C Stafford Park 7, Telford Shropshire TF3 3BQ, England, United Kingdom

Authorized Signature/date:

I, the undersigned, do hereby declare that the equipment specified above conforms to the above Directive(s) and Standard(s).

Signature: _____

Full Name: Robert B. Wilcox

Position: Engineering Manager

Location: Huck International, LLC d/b/a Arconic Fastening Systems and Rings
Kingston, New York, USA

Date: 01/11/2016 (November 1, 2016)



Declared dual number noise emission values in accordance with ISO 4871

A weighted sound power level, LWA: **91** dB (reference 1 pW) Uncertainty, KWA: 3 dB

A weighted emission sound pressure level at the work station, LpA: **80** dB (reference 20 µPa) Uncertainty, KpA: 3 dB

C-weighted peak emission sound pressure level, LpC, peak: **115** dB (reference 20 µPa) Uncertainty, KpC: 3 dB

Values determined according to noise test code ISO 3744. The sum of a measured noise emission value and its associated uncertainty represents an upper boundary of the range of values which is likely to occur in measurements.

Declared vibration emission values in accordance with EN 12096


Measured Vibrations emission value, a:	.63 m/s²
Uncertainty, K:	.72 m/s²
Values measured and determined according to ISO 28662-1, ISO 5349-2, and EN 1033	


Test data to support the above information is on file at:
Arconic Fastening Systems and Rings, Kingston Operations, Kingston, NY, USA.





Safety Instructions

GLOSSARY OF TERMS AND SYMBOLS:

 Product complies with requirements set forth by the relevant European directives.

 Read manual prior to using this equipment.

 Eye protection is required while using this equipment.

 Hearing protection is required while using this equipment.

Notes: are reminders of required procedures.

Bold, Italic type, and underline: emphasize a specific instruction.

 **WARNINGS: Must be understood to avoid severe personal injury.**

 **CAUTIONS: Show conditions that will damage equipment or structure.**

I. GENERAL SAFETY RULES:

1. A half hour long hands-on training session with qualified personnel is recommended before using Huck equipment.
2. Huck equipment must be maintained in a safe working condition at all times. Tools and hoses should be inspected at the beginning of each shift/day for damage or wear. Any repair should be done by a qualified repairman trained on Huck procedures.
3. For multiple hazards, read and understand the safety instructions before installing, operating, repairing, maintaining, changing accessories on, or working near the assembly power tool. Failure to do so can result in serious bodily injury.
4. Only qualified and trained operators should install, adjust or use the assembly power tool.
5. Do not modify this assembly power tool. This can reduce effectiveness of safety measures and increase operator risk.
6. Do not discard safety instructions; give them to the operator.
7. Do not use assembly power tool if it has been damaged.
8. Tools shall be inspected periodically to verify all ratings and markings required, and listed in the manual, are legibly marked on the tool. The employer/operator shall contact the manufacturer to obtain replacement marking labels when necessary. Refer to assembly drawing and parts list for replacement.
9. Tool is only to be used as stated in this manual. Any other use is prohibited.
10. Read MSDS Specifications before servicing the tool. MSDS specifications are available from the product manufacturer or your Huck representative.
11. Only genuine Huck parts shall be used for replacements or spares. Use of any other parts can result in tooling damage or personal injury.
12. Never remove any safety guards or pintail deflectors.
13. Never install a fastener in free air. Personal injury from fastener ejecting may occur.
14. Where applicable, always clear spent pintail out of nose assembly before installing the next fastener.
15. Check clearance between trigger and work piece to ensure there is no pinch point when tool is activated. Remote triggers are available for hydraulic tooling if pinch point is unavoidable.
16. Do not abuse tool by dropping or using it as a hammer. Never use hydraulic or air lines as a handle or to bend or pry the tool. Reasonable care of installation tools by operators is an important factor in maintaining tool efficiency, eliminating downtime, and preventing an accident which may cause severe personal injury.
17. Never place hands between nose assembly and work piece. Keep hands clear from front of tool.
18. Tools with ejector rods should never be cycled with out nose assembly installed.
19. When two piece lock bolts are being used always make sure the collar orientation is correct. See fastener data sheet for correct positioning.

II. PROJECTILE HAZARDS:

1. Risk of whipping compressed air hose if tool is pneudraulic or pneumatic.
2. Disconnect the assembly power tool from energy source when changing inserted tools or accessories.
3. Be aware that failure of the workpiece, accessories, or the inserted tool itself can generate high velocity projectiles.
4. Always wear impact resistant eye protection during tool operation. The grade of protection required should be assessed for each use.
5. The risk of others should also be assessed at this time.
6. Ensure that the workpiece is securely fixed.
7. Check that the means of protection from ejection of fastener or pintail is in place and operative.

8. There is possibility of forcible ejection of pintails or spent mandrels from front of tool.

III. OPERATING HAZARDS:

1. Use of tool can expose the operator's hands to hazards including: crushing, impacts, cuts, abrasions and heat. Wear suitable gloves to protect hands.
2. Operators and maintenance personnel shall be physically able to handle the bulk, weight and power of the tool.
3. Hold the tool correctly and be ready to counteract normal or sudden movements with both hands available.
4. Maintain a balanced body position and secure footing.
5. Release trigger or stop start device in case of interruption of energy supply.
6. Use only fluids and lubricants recommended by the manufacturer.
7. Avoid unsuitable postures, as it is likely for these not to allow counteracting of normal or unexpected tool movement.
8. If the assembly power tool is fixed to a suspension device, make sure that fixation is secure.
9. Beware of the risk of crushing or pinching if nose equipment is not fitted.

IV. REPETITIVE MOTION HAZARDS:

1. When using assembly power tool, the operator can experience discomfort in the hands, arms, shoulders, neck or other parts of the body.
2. When using tool, the operator should adopt a comfortable posture while maintaining a secure footing and avoid awkward or off balanced postures.
3. The operator should change posture during extended tasks to help avoid discomfort and fatigue.
4. If the operator experiences symptoms such as persistent or recurring discomfort, pain, throbbing, aching, tingling, numbness, burning sensations or stiffness, these warnings should not be ignored. The operator should tell the employer and consult a qualified health professional.

V. ACCESSORIES HAZARDS:

1. Disconnect tool from energy supply before changing inserted tool or accessory.
2. Use only sizes and types of accessories and consumables that are recommended. Do not use other types or sizes of accessories or consumables.

VI. WORKPLACE HAZARDS:

1. Be aware of slippery surfaces caused by use of the tool and of trip hazards caused by the air line or hydraulic hose.
2. Proceed with caution while in unfamiliar surroundings; there could be hidden hazards such as electricity or other utility lines.
3. The assembly power tool is not intended for use in potentially explosive environments.
4. Tool is not insulated against contact with electrical power.
5. Ensure there are no electrical cables, gas pipes, etc., which can cause a hazard if damaged by use of the tool.

VII. NOISE HAZARDS:

1. Exposure to high noise levels can cause permanent, disabling hearing loss and other problems such as tinnitus, therefore risk assessment and the implementation of proper controls is essential.
2. Appropriate controls to reduce the risk may include actions such as damping materials to prevent workpiece from 'ringing'.
3. Use hearing protection in accordance with employer's instructions and as required by occupational health and safety regulations.
4. Operate and maintain tool as recommended in the instruction handbook to prevent an unnecessary increase in the noise level.
5. Select, maintain and replace the consumable / inserted tool as recommended to prevent an unnecessary increase in noise.
6. If the power tool has a silencer, always ensure that it is in place and in good working order when the tool is being operated.

VIII. VIBRATION HAZARDS:

1. Exposure to vibration can cause disabling damage to the nerves and blood supply to the hands and arms.
2. Wear warm clothing when working in cold conditions and keep hands warm and dry.
3. If numbness, tingling, pain or whitening of the skin in the fingers or hands, stop using the tool, tell your employer and consult a physician.
4. Support the weight of the tool in a stand, tensioner or balancer in order to have a lighter grip on the tool.

IX. PNEUMATIC / PNEUDRAULIC TOOL SAFETY INSTRUCTIONS:

1. Air under pressure can cause severe injury.
2. Always shut off air supply, drain hose of air pressure and disconnect tool from air supply when not in use, before changing accessories or when making repairs.
3. Never direct air at yourself or anyone else.
4. Whipping hoses can cause severe injury, always check for damaged or loose hoses and fittings.
5. Cold air should be directed away from hands.
6. Whenever universal twist couplings (claw couplings) are used, lock pins shall be installed and whip-check safety cables shall be used to safeguard against possible hose to hose or hose to tool connection failure.
7. Do not exceed maximum air pressure stated on tool.
8. Never carry an air tool by the hose.



Specifications

STROKE:

1.275 in (3.24 cm)

WEIGHT:

11.0 lbs (5.0 kg)

MAX AIR PRESSURE:

90 psi (6.2 bar)

MAX FLOW RATE:

22.4 scfm (634.37 l/min)

CAPACITY:

6700 lbs @ 90 psi (29.80 kN @ 6.2 bar)

SPEED / CYCLES:

30 per minute

MAX OPERATING TEMP:

125° F (51.7° C)

POWER SOURCE:

Huck Powerig® hydraulic power source

HYDRAULIC FLUID:

Hydraulic fluid shall meet DEXRON® III, DEXRON VI, MERCON®, Allison C-4 or equivalent Automatic Transmission Fluid (ATF) specifications. Fire-resistant fluid may be used if it is an ester-based fluid such as Quintolubric® HFD or equivalent. Water-based fluid shall NOT be used as serious damage to equipment will occur.






Figure 1

INCHES
(mm)



Where the following trade names are used in this manual, please note:

DEXRON is a registered trademark of General Motors Corporation.

Loctite is a registered trademark of Henkel Corporation, U.S.A.

LUBRIPLATE is a registered trademark of Fiske Brothers Refining Co.

MERCON is a registered trademark of Ford Motor Corp.

Never-Seez is a registered trademark of Bostik, Inc.

Quintolubric is a registered trademark of Quaker Chemical Corp.

Slic-tite is a registered trademark of LA-CO Industries, Inc.

Teflon is a registered trademark of E. I. du Pont de Nemours and Company.

Threadmate is a registered trademark of Parker Intangibles LLC.

TRUARC is a trademark of TRUARC Co. LLC.

Vibra-Tite is a registered trademark of ND Industries, Inc. USA.

Principle of Operation

PULL STROKE

When the trigger is pressed, the throttle valve moves down to the PULL position, and pressurized air is directed to the bottom of the air piston, causing it to move upward. The air above the air piston is exhausted and directed through the center of the throttle valve and out the bottom of the tool. The air piston has a rod and a hydraulic piston attached. As the air piston rod moves upward, a column of pressurized fluid is forced into the head, which moves the pull piston rearward. The attached nose assembly moves with the pull piston spindle to start the fastener installation.

RETURN STROKE

When fastener installation is completed, the trigger is released. Air pressure, with the assistance of a spring, sends the throttle valve to the up (RETURN) position. Pressurized air is re-directed to the top of the air piston, causing the air piston to move downward. The air from below the piston is exhausted through the bottom of the tool. The rod and hydraulic piston move downward; hydraulic pressure is reversed and the pull piston is returned forward. The return pressure relief valve protects the tool against pressure spikes. The reservoir replenishes the hydraulic system as needed.



Operating Instructions

Read and understand all WARNINGS, CAUTIONS, and instructions before operating this equipment.



WARNINGS:

To avoid severe personal injury, wear approved eye and hearing protection.

Pins eject with great velocity when pintails break off or teeth/grooves strip. Serious personal injury may occur to anyone in the pin's "flight path." This includes pins that ricochet.

Ensure adequate clearance for operator's hands before installing fasteners.

Do not pull on a pin without placing a fastener/collar in a workpiece.

Make sure that the collar chamfer faces toward the tool.



CAUTIONS:

Remove any excess gap from between the sheets to permit proper fastener installation and prevent jaw damage.

Ensure tool has been properly re-assembled prior to use.

ALL jaw teeth must engage the pintail to avoid damaging the teeth.

GENERAL PRECAUTIONS

If the tool malfunctions, consult **TROUBLESHOOTING** in this manual prior to attempting any repairs. Operators should receive training from qualified personnel. Do not bend tool to free if stuck. The tool should only be used to install fasteners. Never use as a jack/spreader or hammer.

NOTE: Reasonable care of tools by operators is an important factor in maintaining tool efficiency and reducing downtime.

TO INSTALL A BobTail® FASTENER

The length of the tool increases during fastener installation. Allow adequate tool and anvil clearance before installing fasteners.

Check pin for correct grip. Place a pin in the workpiece and place the collar over the pin. **NOTE: If the collar has one tapered end, that end must be out toward tool; not next to the sheet.**

Hold the pin in the hole and push the nose assembly onto the pin protruding through the collar until the nose anvil touches the collar.

Move hands away from pin and structure. Keep hands away from front of tool during operation; tool anvil advances forward.


Hold tool at right angle (90 degrees) to work. Press and hold the trigger until the collar is swaged and the pintail breaks.

Release the trigger; the tool will perform its RETURN stroke. The pressure is re-directed; the piston moves forward; and the tool is pushed off the fastener and ready for the next installation cycle.

Measuring Tool Stroke

1. With the piston in the full-forward position, measure **DISTANCE A** from face of the cylinder to the face of the piston.
2. Cycle the tool and keep the piston in the full-rearward position by holding the trigger pressed. Measure **DISTANCE B** as above.

$$\text{TOOL STROKE} = \text{DISTANCE B} - \text{DISTANCE A}$$





Maintenance



WARNING: Inspect tool for damage and wear before each use. Do NOT operate if damaged or worn as serious personal injury may occur.



CAUTIONS:
Consult the Material Safety Data Sheet (MSDS) before servicing tool.

Keep foreign matter out of the hydraulic system. Keep separated parts away from dirty work surfaces.

Dirt and debris in hydraulic fluid causes valve failures in tool and the Powerig® hydraulic power source.

Replace all seals, wipers, and rings when the tool is disassembled for any reason, and at regular intervals, depending on severity and length of use.

Do not use Teflon® tape on pipe threads. Tape can shred, resulting in malfunctions.

NOTE: See SPECIFICATIONS for fluid type. Dispose of fluid in accordance with local environmental regulations. Recycle steel, aluminum, and plastic parts in accordance with local lawful and safe practices.

GENERAL

The operating efficiency of your tool is directly related to the performance of the entire system. Regular inspection and the immediate correction of minor problems will keep the tool operating efficiently, and prevent downtime. A schedule of "preventive" maintenance of the tool, nose assembly, hoses, trigger and control cord, and Powerig will ensure proper tool operation and extend its life.

NOTE: Huck tools should be serviced only by personnel who are thoroughly familiar with its operation.

Service the tool in a clean, well-lighted area. Take special care to prevent contamination of pneumatic and hydraulic systems.

Have available all necessary hand tools—standard and special.

Disassemble and assemble tool components in a straight line. Do NOT bend, cock, twist, or apply undue force.

Carefully handle all parts. Before reassembly, examine them for damage and wear.

Have the appropriate Spare Parts Service Kit (**256BTKIT**) available when servicing the tool; it includes important perishable parts. Other components, as experience dictates, should also be available. See KITS & ACCESSORIES.

Smear LUBRIPLATE® 130-AA (Huck P/N **502723**) or SUPER-O-LUBE® (Huck P/N **505476**) on O-rings, Quad-rings, Back-up rings, and mating parts to ease assembly.

Apply Parker Threadmate®, Loctite® 567, or Slic-Tite® to male pipe threads, hose fitting threads, and quick connect fittings (per manufacturer's instructions) to prevent leaks and to ease assembly.

DAILY

Check the fluid level in the tool reservoir; replenish as necessary. If a Filter-Regulator-Lubricator is not being used, uncouple the air disconnects and add a few drops of fluid or a light-weight oil to the air inlet of the tool.

NOTE: If the tool is in continuous use, add a few drops of fluid every 2–3 hours.

Before connecting an air hose to the tool, clear the air lines of dirt and water.

Check all hoses and couplings for damage and air leaks; tighten or replace if necessary. Check the tool for damage and air or hydraulic leaks; tighten, repair, or replace if necessary.

Inspect the tool, hoses, and Powerig during operation to detect abnormal heating, leaks, or vibration.

Check the nose assembly for tightness and damage.

Clean nose assemblies in mineral spirits to clear jaws and rinse metal chips and dirt. For a more thorough cleaning, disassemble the nose assembly. Use a pointed "pick" to remove embedded particles from the pull grooves of the jaws.

Clean all parts of any assembly with UNITIZED™ Jaws in mineral spirits or isopropyl alcohol only; do not let jaws come in contact with other solvents. Do not let jaws soak; dry them *immediately* after cleaning. Huck recommends drying other parts before re-assembling.

Periodically, check the tool stroke. If the stroke is short, add fluid. See MEASURING TOOL STROKE.

WEEKLY

Disassemble, clean, and re-assemble nose assembly in accordance with applicable instructions.

Check the tool and all connecting parts for damage and fluid/air leaks; tighten or replace if necessary.



Disassembly



WARNING: Disconnect the air hose from the tool before performing any maintenance. Serious personal injury could result if the air hose is connected.



CAUTION: Always use a soft-jaw vise to avoid damaging the tool.

This procedure is for complete disassembly of the tool. Disassemble **only** those components necessary to replace damaged O-rings, Quad-rings, Back-up rings, and worn and damaged components.

1. Disconnect air hose from tool.
 2. Remove nose assembly.
 3. Insert Fill Tool (P/N **112465**) through reservoir housing and screw it into the reservoir plunger, locking it in the out position. (Figure 2)
 4. Unscrew cap screws with a 5/32" hex key, and carefully separate head from handle. Remove the pull and return gland assemblies, and remove the seals from the glands. (Figure 2)
 5. Unscrew the relief valve plug from the front of the head. Then remove the spring, guide, ball, and sleeve. A small magnet is helpful.
 6. Unscrew the bleed plug. Slowly release the fill tool, and drain the fluid into a container. Discard the fluid.
 7. Unscrew the reservoir housing from the head. Then remove the two springs, and slide the reservoir plunger out of the head. Remove the spacer and use a pick to remove the Quad-ring.
 8. Unscrew the check valve plug from the side of the head. Then remove the spring, guide, and ball. (Figure 2)
- NOTE: If the check valve seat is damaged, it must be replaced; it cannot be re-used. Contact your Huck representative. It can be removed by using the following procedure.**
9. Check Valve Seat Assembly Removal: All parts in the reservoir check valve must be removed before the plug can be removed. Use a 3/16" Allen wrench to remove the screw. Then insert a #10 screw in the thread of the plug, and pull to remove. Use the optional Seat Removal Tool (P/N **126136**) or a small drift and hammer, and from the rear of the head, drive the assembly out through the front of the head. (Fig. 9)
 10. Unscrew the cylinder cap from the head with 1-11/16" open-end wrench.
 11. Remove piston through rear of tool. **NOTE: Piston should push out the front and rear gland assemblies.**
 12. Remove two screws from the throttle arm guard; remove guard.
 13. Remove the screw from the throttle arm, and then remove the throttle arm. Remove the throttle valve and spring from the cylinder. (Figure 9)
 14. With a small punch and hammer, drive out roll pin to remove the trigger from the handle. (Figure 9) Remove the trigger pin. Remove ball end of the cable from the throttle arm, and pull cable out of handle.
 15. Remove the bleed plug from the handle. (Figure 2)
 16. Secure the tool upside-down in a soft-jaw vise, and use a 1/8" hex key to unscrew the 4 button-head screws; then remove the muffler end cap, bottom exhaust gasket, muffler and O-ring. (Figure 3)
 17. Tap the cylinder head down into the cylinder; then remove the retaining ring from the cylinder assembly. (Figure 3)
 18. Screw the button-head screws into the cylinder head, and carefully pry on them to remove the cylinder head.




Figure 2



Disassembly (continued)

20. Push air piston all the way down in the cylinder, remove tool from vise, and lay on its side. Hold the self-locking nut with a 9/16" socket and extension, and use a 7/64" hex key to remove the piston screw. (Figures 4 & 9)
21. Secure the cylinder assembly and handle upside-down in a vise again. Use pliers to grip the self-locking nut and pull out the air piston and rod assembly from the handle and cylinder assemblies.



CAUTION: DO NOT scratch the piston, rod, or cylinder when removing.

22. Use a 1-3/8" socket and extension to remove the gland assembly. The handle and cylinder assemblies will now separate. (Figure 3)
23. Push the piston rod out of the handle. Push out from top to bottom.




CAUTION: Use a plastic or wooden drift to avoid damaging the handle bore.

24. Remove the retaining ring and spacer from the gland assembly, then remove the Polyseal. The tool has been properly disassembled. Store all *re-usable* parts (screws and disassembled components) in a clean, dry area.



WARNING: Do NOT re-use seals, wipers, or rings; irreparable tool damage could occur. Discard these parts and use replacements (see [KITS & ACCESSORIES](#)).

Figure 3





Assembly



WARNINGS: Do not omit any seals during servicing, leaks will result and personal injury may occur.

Make sure tool is fully assembled, with all components included.

This procedure is for the assembly of the tool.

Before re-assembling the tool:

- Clean components with mineral spirits or a similar solvent. Inspect for wear/damage and replace as necessary.
- Replace all seals of disassembled components.
- Use the O-rings, Quad-rings, and Back-up rings from Huck Spare Parts Service Kit (P/N **256BTKIT**).

When assembling the tool, take care not to damage O-rings, Quad-rings, Back-up rings.

Smear LUBRIPLATE® 130-AA (Huck P/N **502723**) or SUPER-O-LUBE® (Huck P/N **505476**) on rings and mating parts to ease assembly.

To re-assemble the tool:

1. Secure the head upside-down in a soft-jaw vise. (Figure 3) Place the inverted cylinder assembly on the handle. (The timing pin maintains orientation.) Assemble the gland assembly with new seals. Apply an anti-seize compound (P/N **508183**) to the threads. Screw the assembly into the head and use a 1-3/8" socket wrench to torque to 100–120 ft.-lbs.
2. Clean the piston rod (P/N **130296**) threads and treat with Loctite® 243™. Carefully press the assembled air piston and piston rod (with Quad-ring in place) all the way into the cylinder.




CAUTION: Take care to not scratch the piston, rod, or cylinder.

3. Turn tool upright. Install the Hydraulic Piston Assembly (with rings in place) in the handle. Press from the top of the handle without damaging seals. (Figure 4)
4. Push screw (with O-ring in place) through the hydraulic piston and screw into top of piston rod. Hold self-locking nut with a 9/16" socket and extension, and use a 7/64" hex key to torque the screw to 55–60 in.-lbs.
5. Secure the head upside-down in a vise. Push the cylinder head (with O-ring in place) squarely into the cylinder, taking care not to damage O-ring. Install the retaining ring. (Figures 3 & 9)
6. Position the O-ring and muffler in the center of the cylinder assembly. Position the gasket on the cylinder assembly, taking care to note the direction of the lip in Figure 3. Carefully position the gasket and muffler

end cap on the cylinder, making sure that the muffler end cap is properly positioned in the recess of the bottom plate. Secure muffler end cap with three button-head screws using a 1/8" hex key.

7. Place the tool upright on a level surface. Drop the spring into the throttle valve hole in the cylinder, and push the throttle valve assembly (with rings in place) into the cylinder.
8. Assemble the trigger cable and trigger pin, and slide cable into the handle. Align the hole in the trigger with the hole in the handle and install the roll pin with a hammer and punch.

Figure 4




9. Slide the throttle arm onto the ball end of the throttle cable. Swing the arm until the other end fits over the throttle valve. Push the screw through the throttle arm and tighten with 5/32" hex key.
 10. Reinstall the air hose assembly if it was removed.
- NOTE:** If replacing the seat assembly: Push the plug, with rings in place, into the head; insert and tighten the screw. (Figure 9)
11. Install the O-ring and Back-up ring onto seat. Drive in the seat assembly using a soft drift, taking care not to damage the ball seat surface. (Figure 9, Section A-A)
 12. Assemble the pull piston with new seals that have been lubricated with LUBRIPLATE® 130-AA or SUPER-O-LUBE®. (Figures 9 & 10)



Assembly (continued)

13. Assemble the front gland assembly (with seals, housing, and wiper), and push over the Assembly Bullet and onto the Pull Piston Assembly. (Figures 9 & 10)
14. Install the O-rings and Back-up rings on the rear gland assembly. Push the assembly into the head; screw in the end cap and tighten. (Figures 9 & 10)
15. Install the O-ring and Back-up ring on the relief valve plug. (Figure 10) Insert the ball, guide, sleeve, spring, and plug into the head.
16. Install the O-ring on the check valve plug. Insert the ball, guide, spring, and plug into the head.
17. Push pintail deflector onto the barbed end of the pull piston.
18. Screw the bleed plug assemblies (with O-ring in place) into the handle and cylinder head. (Figure 9)
19. Install the O-rings and Back-up rings on the pull gland assembly; and the O-rings and Back-up rings on the return gland assembly. Push these assemblies into the handle. (Figure 5) Push the head down onto the handle, aligning it with the pull and return gland assemblies. Place the tool upside-down in a vise, and install the 4 cap screws; torque to 170 in-lbs.

The tool is now assembled and must be filled with hydraulic fluid prior to use. See **FILL AND BLEED**.



Assembly of NPTF Threaded Components

AIR FITTINGS

- 1) Apply TEFLON® stick to male threads which do not have pre-applied sealant per manufacturer's recommendations. (Proceed to All Fittings step 2)

HYDRAULIC FITTINGS

- 1) Apply Threadmate™ to male and female threads which do not have pre-applied sealant per manufacturer's recommendations. (Proceed to All Fittings step 2)

ALL FITTINGS:

- 2) Tighten to finger-tight condition.
- 3) Wrench tighten to 2-3 turns past finger-tight condition.
- 4) Final thread engagement can be checked (optional) by measuring the dimension from the flange of male fitting to the end of the thread before assembly and subtracting the distance under the flange after assembly.

THREAD SIZE	FINAL THREAD ENGAGEMENT AT FULL MAKE-UP
1/8-27 NPTF	.235 inch (.59 cm)
1/4-18 NPTF	.339 inch (.86 cm)
3/8-18 NPTF	.351 inch (.89 cm)



Fill and Bleed

This section documents the “bleed-&-fill” procedure. For component identification, see Figures 6, 7, & 8.

REQUIRED EQUIPMENT

- DEXRON® III or equivalent ATF (See **SPECIFICATIONS** for more information.)



WARNING: Avoid contact with hydraulic fluid. Hydraulic fluid must be disposed of in accordance with local regulations. See MSDS for hydraulic fluid shipped with tool.

- Shop air-line with 90–100 psi (6.2–6.9 BAR) max.
- Air regulator
- Large flat-blade screwdriver
- Fill Bottle (P/N **120337**, included with tool)
- Nose assembly or Stall Nut (P/N **120824**), optional
- Fasteners (optional)

PREPARATION

- Install the air regulator in the air-line and set the pressure to 20–40 psi (1.4–2.8 BAR).
- Add an approved hydraulic fluid to the fill point of the Fill Bottle. (Figure 6)

NOTE: Refill the tool only when the fluid level drops below the red line on the reservoir housing; or when the tool is rebuilt.




Figure 6



CAUTION: Purge all fluid from the tool before refilling. The tool stroke will be diminished if the fluid is aerated.

For optimal performance, refill with a fluid that is recommended in **SPECIFICATIONS.**

To bleed and fill the tool:

- Screw the Fill Tool into the reservoir plunger. Pull the plunger into the reservoir housing and lock the Fill Tool in the full-forward position by tilting the handle (long side touching tool) and locking it in place. (Figure 7)
- Remove the relief valve plug and the check valve plug (Figure 7), as well as all guides, springs, and balls, from the ports in the head. Re-insert the relief valve plug. (Figures 7 & 8)
- Screw the retaining nut onto the head assembly, and screw the stall nut onto the hydraulic piston. Tighten to ensure full thread engagement.

NOTE: Back off the retaining nut until it engages the stall nut. Verify that the hydraulic piston is full





Figure 7

forward and locked with the retaining nut (and, optionally, with the stall nut).

NOTE: If the stall nut is not used, the piston must be pushed to the full-forward position before installing the valves.

- Connect the tool to the air source to seat the air piston at the bottom of the air cylinder; then disconnect. Lay tool on its side with the fill port facing up.
- Insert the fill bottle in the fill port (check valve hole). (Figures 7 & 8)

Figure 8





Fill and Bleed (continued)

6. Connect the tool to the air supply and cycle it 20–30 times; watch for air bubbles escaping into the bottle. (Rock the tool to free trapped air.)




WARNING: Air pressure must be set at 20–40 psi (1.4–2.8 BAR) to prevent possible injury from high-pressure spray.

If the plug is removed, the fill bottle must be in place before cycling the tool.

NOTE: Do not allow air to re-enter the tool. When cycling the tool, hold the fill bottle as shown in Figure 8 to prevent drawing in air.

7. When air bubbles stop accumulating in the fill bottle, stop cycling the tool. Remove the bottle and replace the plug.
8. Install the check valve ball, guide, and spring. Replace the check valve plug.
9. Turn the tool so the front of the head faces you. Back out (approximately 1/2 turn counterclockwise) the setscrew that is inside the relief valve plug. (This ensures that the piston remains in the full-forward position.) Remove the relief valve plug; insert the ball, guide, sleeve, and spring, and then re-insert the plug. After bleeding, re-tighten the setscrew.

FIGURE 8A



10. Unlock the Fill Tool and check the fluid level (Red line indicator, Figure 7) in the reservoir housing. Cycle the tool with the stall nut attached and the retaining nut locked in the full-forward position ("dead stall"). The fluid level should not drop below the red line on the reservoir housing. **NOTE:** If the stall nut was not used, Dead Stalling is not necessary; just cycle tool.

11. Re-lock the fill tool in out position. Lay the tool on its side with the reservoir facing up, and remove the bleed plug. Insert the fill bottle and add a few drops of fluid to the reservoir; wait for air bubbles to escape, then remove the fill bottle. (Push a pin or a scribe into the reservoir fill port to check for trapped air bubbles.) Replace the plug. (Figures 7 & 8A)



WARNING: Failure to re-lock the fill tool will result in oil ejecting from the head under pressure during the topping off of the reservoir.

Severe personal injury may result.

12. Unlock the Fill Tool, cycle the tool as in step 10, and check the fluid level in the reservoir housing. The reservoir fluid level may drop slightly. If so, repeat these steps until, when the Fill Tool handle is touched, it has no pressure against it and it drops out of the lock position, and the fluid level in the reservoir housing does not drop when the tool is cycled.

NOTE: This usually requires 3 to 4 repetitions.




WARNING: Air pressure must be set at 20–40 psi (1.4–2.8 BAR) to prevent possible injury from high-pressure spray.

If the plug is removed, the fill bottle must be in place before cycling the tool.

13. When the fluid level is sufficient, remove the Fill Tool and stall nut. Install a nose assembly and pull several fasteners to test function.

Assembly Drawing


FIGURE 9






Assembly Drawing


FIGURE 10




10 - Front Gland Assy



11 - Pull Piston Assy



12 - Rear Gland Assy



33 - Bleed Plug / O-Ring Assy

Parts List

Refer to Figures 9 and 10

Item	Description	Part No.	Qty.
1	Handle & Sleeve Assembly	125642	1
2	Cable	125643	1
3	Trigger	124333-2	1
4	Trigger Pin	505496	1
5	Roll Pin	500621	1
6	Wiper Housing	129549	1
7	Stop	110670	1
8	Retaining Nut	117824	1
9	Head Assembly contains:	129552	1
9a	Cylinder Head *	n/a	1
9b	Seat	111139	1
9c	Pin	120203	1
10	Front Gland Assembly contains:	129556	1
10a	Front Gland *	n/a	1
10b	Polyseal	505865	1
10c	O-ring	500820	1
10d	Back-up Ring	501114	1
11	Pull Piston Assembly contains:	129555	1
11a	Pull Piston *	n/a	1
11b	Back-up Ring	501144	2
11c	O-ring	500850	1
12	Rear Gland Assembly contains:	129557	1
12a	Rear Gland *	n/a	1
12b	O-ring	505887	1
12c	Back-up Ring	501118	1
12d	Polyseal	508428	1
13	Cylinder Cap	129550	1
14	Wiper	505894	1
15	Return Gland Assembly contains:	112502	1
15a	Return Gland *	n/a	1
15b	O-ring	500776	1
15c	Back-up Ring	501082	1
15d	O-ring	500778	1
15e	Back-up Ring	501084	1
16	Throttle Arm Setscrew	502053	1
17	Throttle Valve Assembly contains:	115558	1
17a	Throttle Valve *	n/a	1
17b	O-ring	504408	2
17c	O-ring	504407	1
17d	Spring	116272	1
18	Button Head Screw	500101	4
19	Self-locking Nut	121241	1
20	Muffler End Cap	120076	1

* When replacing these parts, the assembly must be ordered. They are not sold separately.

Parts List continued on next page...



Parts List

Refer to Figures 9 and 10

Item	Description	Part No.	Qty.	Item	Description	Part No.	Qty.
21	Muffler	115554	1	32	Cap Screw	500102	4
22	O-ring	500777	1	33	Bleed Plug / O-ring Assembly contains:	104243	3
23	Gasket	126941-3	1	33a	Bleed Plug *	n/a	1
24	Retaining Ring	505139	1	33b	O-ring	505438	1
25	Cylinder Head Assembly contains:	113528	1	34	Screw	502482	2
25a	Cylinder Head *	n/a	1	35	Screw & Bushing Assembly	127029	1
25b	O-ring	505147	1	36	Throttle Arm	127688	1
26	Piston / Quad-ring Assembly contains:	113526	1	37	Guard	125657	1
26a	Air Piston *	n/a	1	38	Air Hose Assembly	115436	1
26b	Quad-ring	501472	1	39	Spring	505864	2
27	Piston Rod	113344	1	40	Housing / Spacer Assembly	112403	1
28	Cylinder Assembly	120372	1	41	Quad-ring	501408	1
29	Gland Assembly contains:	127326	1	42	Reservoir Plunger	112405	1
29a	Gland	127324	1	43	Check Valve Ball	502929	1
29b	Gland Housing	127325	1	44	Check Valve Guide	111067	1
29c	Back-up Ring	127327	1	45	Spring	100874	1
29d	Back-up Ring	127328	1	46	Screw	120129	1
29e	Polyseal	127329	1	47	Back-up Ring	501082	2
29f	O-ring	500779	1	48	O-ring	505446	2
29g	O-ring	500781	1	49	O-ring	505438	1
29h	O-ring	500784	1	50	Plug	111068	1
29j	O-ring	500786	1	51	Plug	120204	1
29k	Retaining Ring	502821	1	52	Seat & Seals Assembly contains:	114537	1
30	Hydraulic Piston Assembly contains:	118866	1	52a	Seat *	n/a	1
30a	Hydraulic Piston *	n/a	1	52b	Back-up Ring	501082	2
30b	Screw	117773	1	52c	O-ring	505446	1
30c	O-ring	503770	1	53	Relief Valve Ball	502506	1
30d	Back-up Ring	501086	2	54	Relief Valve Guide	120128	1
30e	O-ring	500773	1	55	Sleeve	120127	1
31	Pull Gland Assembly contains:	113532	1	56	Spring	505863	1
31a	Pull Gland *	n/a	1	57	Relief Valve Plug	114530	1
31b	O-ring	500776	1				
31c	Back-up Ring	501082	1				
31d	Back-up Ring	501090	1				
31e	O-ring	500784	1				

* When replacing these parts, the assembly must be ordered. They are not sold separately.



Troubleshooting

Always check the simplest possible cause (such as a loose or disconnected trigger line) of a malfunction first. Then proceed logically, eliminating other possible causes until the cause is discovered. Where possible, substitute known good parts for suspected defective parts. Use this Troubleshooting information to aid in locating and correcting trouble.

NOTE: "Piston drift" is when the air piston is in the down position, but the hydraulic pull piston is not in the full-forward position. This causes an out-of-sequence condition.

1. Tool fails to operate when trigger is pressed.
 - a. Air-line not connected.
 - b. Worn or damaged throttle valve O-rings.
 - c. Broken throttle valve cable assembly.
2. Tool does not complete fastener installation and break pintail.
 - a. Air pressure too low.
 - b. Worn or damaged air piston Quad-ring.
 - c. Tool is low on hydraulic fluid, or empty. See the FILL AND BLEED section.
 - d. Air in the hydraulic system. See the FILL AND BLEED section.
 - e. Worn or damaged reservoir springs.
 - f. Check for piston drift.
3. Pintail stripped and/or swaged collar not ejected.
 - a. Check for broken or worn jaws in nose assembly. See Nose Assembly Data Sheet.
 - b. Check for loose retaining nut.
 - c. Check for piston drift.
4. Hydraulic fluid exhausts with air or leaks at base of handle.
 - a. Worn or damaged gland assembly. Inspect Polyseal, O-rings, and Quad-ring. Replace if necessary.
5. Tool has piston drift.
 - a. Loose collet crashing into the front of the anvil causing the relief valve to open, allowing the piston to drift. Tighten the collet. See the FILL AND BLEED section.
 - b. Worn or damaged return pressure relief valve. Inspect seat assembly, O-ring, Back-up rings, steel ball, and valve spring. Replace if necessary.
 - c. Worn or damaged Piston Assembly. Inspect O-rings and Back-up rings. Replace if necessary.
6. Hydraulic fluid leaks at rear of pull piston.
 - a. Worn or damaged rear gland. Inspect Polyseal and O-ring. Replace if necessary.
7. Hydraulic fluid leaks at front of pull piston.
 - a. Worn or damaged front gland. Inspect Polyseal, O-ring, and Back-up ring. Replace if necessary.
8. Pull piston will not return.
 - a. Throttle valve stuck; lubricate O-rings.
 - b. Throttle arm, cable, or trigger binding.
9. Air leaks at air cylinder head.
 - a. Worn or damaged O-ring. Replace if necessary.

Kits & Accessories

Huck has created product-specific Spare Parts Service Kits that contain various perishable parts for each tool. The types and quantities of spare parts that should be available vary with the application and tools in use. Have the appropriate kit accessible when using this tool and when performing maintenance on it.

Huck also recommends having the following Accessories available when preparing, using, and performing maintenance on this tool.

KITS

Service Kit - 256BTKIT

ACCESSORIES

Stall Nut	- 120824
Seat Removal Tool	- 126136
Fill and Bleed Bottle	- 120337
Fill Tool Assembly (for reservoir)	- 112465



Limited Warranties

Limited Lifetime Warranty on BobTail® Tools:

Huck International, Inc. warrants to the original purchaser that its BobTail® installation tools manufactured after 12/1/2016 shall be free from defects in materials and workmanship for its **useful lifetime**. This warranty does not cover special order / non-standard products, or part failure due to normal wear, tool abuse or misapplication, or user non-compliance with the service requirements and conditions detailed in the product literature.

Two Year Limited Warranty on Installation Tools:

Huck International, Inc. warrants that its installation tools and Powerigs® manufactured after 12/1/2016 shall be free from defects in materials and workmanship for a period of two years from date of purchase by the end user. This warranty does not cover special order / non-standard products, or part failure due to normal wear, tool abuse or misapplication, or user non-compliance with the service requirements and conditions detailed in the product literature.

90 Day Limited Warranty on Nose Assemblies and Accessories:

Huck International, Inc. warrants that its nose assemblies and accessories shall be free from defects in materials and workmanship for a period of 90 days from date of purchase by the end user. This warranty does not cover special clearance noses, or special order / non-standard product, or part failure due to normal wear, abuse or misapplication, or user non-compliance with the service requirements and conditions detailed in the product literature.

Useful lifetime is defined as the period over which the product is expected to last physically, up to the point when replacement is required due to either normal in-service wear, or as part of a complete overhaul. Determination is made on a case-by case basis upon return of parts to Huck International, Inc. for evaluation.

Tooling, Part(s) and Other Items not manufactured by Huck:

HUCK makes no warranty with respect to the tooling, part(s), or other items manufactured by third parties. HUCK expressly disclaims any warranty expressed or implied, as to the condition, design, operation, merchantability, or fitness for use of any tool, part(s), or other items thereof not manufactured by HUCK. HUCK shall not be liable for any loss or damage, directly or indirectly, arising from the use of such tooling, part(s), or other items or breach of warranty or for any claim for incidental or consequential damages.

Huck shall not be liable for any loss or damage resulting from delays or non-fulfillment of orders owing to strikes, fires, accidents, transportation companies or for any reason or reasons beyond the control of the Huck or its suppliers.

Huck Installation Equipment:

Huck International, Inc. reserves the right to make changes in specifications and design and to discontinue models without notice.

Huck Installation Equipment should be serviced by trained service technicians only.

Always give the serial number of the equipment when corresponding or ordering service parts.

Complete repair facilities are maintained by Huck International, Inc. Please contact one of the offices listed below.

Eastern

One Corporate Drive Kingston, New York 12401-0250
Telephone (845) 331-7300 FAX (845) 334-7333

Outside USA and Canada

Contact your nearest Huck International location (see reverse).

In addition to the above repair facilities, there are Authorized Tool Service Centers (ATSC's) located throughout the United States. These service centers offer repair services, spare parts, Service Parts Kits, Service Tool Kits and Nose Assemblies. Please contact your Huck Representative or the nearest Huck International location (see reverse) for the ATSC in your area.



ARCONIC

Innovation, engineered.

Arconic Inc. (NYSE: ARNC) creates breakthrough products that shape industries. Working in close partnership with our customers, we solve complex engineering challenges to transform the way we fly, drive, build and power.

Through the ingenuity of our people and cutting-edge advanced manufacturing, we deliver these products at a quality and efficiency that ensures customer success and shareholder value.

Arconic Fastening Systems and Rings world-wide locations:

AMERICAS

Kingston Operations

1 Corporate Drive
Kingston, NY 12401
800-278-4825
845-331-7300
FAX: 845-334-7333

Carson Operations

900 Watson Center Rd.
Carson, CA 90745
800-421-1459
310-830-8200
FAX: 310-830-1436

Waco Operations

PO Box 8117
8001 Imperial Drive
Waco, TX 76714-8117
800-388-4825
254-776-2000
FAX: 254-751-5259

Tucson Operations

3724 East Columbia
Tucson, AZ 85714
800-234-4825
520-747-9898
FAX: 520-748-2142

Acuña Operations

Hidalgo #120
Parque Industrial Amistad
26220 Acuña Coahuila
Mexico
FAX: 525-515-1776
TELEX: 1173530 LUKSME

EUROPE

Telford Operations

Unit C, Stafford Park 7
Telford, Shropshire
England TF3 3BQ
01952-290011
FAX: 0952-290459

Us Operations

BP4
Clos D'Asseville
95450 Us par Vigny
France
33-1-30-27-9500
FAX: 33-1-34-66-0600

AUSTRALIA

Melbourne Operations

11508 Centre Road
Clayton, Victoria
Australia 3168
03-764-5500
Toll Free: 008-335-030
FAX: 03-764-5510

Huck is Forever, For the Long Haul, The Future of Fastening Technology, The Future of Assembly Technology, The Future of Tooling Technology, and Tools of Productivity are service marks of Huck International. Huck provides technical assistance regarding the use and application of Huck fasteners and tooling.

NOTICE: The information contained in this publication is only for general guidance with

regard to properties of the products shown and/or the means for selecting such products, and is not intended to create any warranty, express, implied, or statutory; all warranties are contained only in Huck's written quotations, acknowledgments, and/or purchase orders. It is recommended that the user secure specific, up-to-date data and information regarding each application and/or use of such products.



HUCK IS FOREVER.™