



Confidential

Pricing subject to change without notice

IT Installation Tools

Disposable Hand Installation Tool designed for field repairs or consumer installations

Installs Series: CAL, CAK, CAO, CFT, and CFW

Installation Sizes: 6-32 to 3/8-24 (M4 – M10)



IT INSTALLATION TOOL In Bulk Boxes - NUT ONLY			
Thread Size	AVK	SHEREX	Price (each)
6-32	AA181-632	IT-0632 NUT	\$2.84
8-32	AA181-832	IT-0832 NUT	\$2.84
10-24	AA181-1024	IT-1024 NUT	\$2.84
10-32	AA181-1032	IT-1032 NUT	\$2.84
1/4-20	AA181-420	IT-2520 NUT	\$2.84
1/4-28	AA181-428	IT-2528 NUT	\$2.84
5/16-18	AA181-518	IT-3118 NUT	\$2.84
5/16-24	AA181-524	IT-3124 NUT	\$2.84
3/8-16	AA181-616	IT-3716 NUT	\$2.84
3/8-24	AA181-624	IT-3724 NUT	\$2.84
M4	AA181-470	IT-470 NUT	\$2.84
M5	AA181-580	IT-580 NUT	\$2.84
M6	AA181-610	IT-610 NUT	\$2.84
M8	AA181-8125	IT-8125 NUT	\$2.84
M10	AA181-1015	IT-1015 NUT	\$2.84

IT INSTALLATION TOOL Bag with Instructions - NUT and MANDREL			
Thread Size	AVK	SHEREX	Price (each)
6-32	AA184-632	IT-0632	\$4.00
8-32	AA184-832	IT-0832	\$4.00
10-24	AA184-1024	IT-1024	\$4.00
10-32	AA184-1032	IT-1032	\$4.00
1/4-20	AA184-420	IT-2520	\$4.00
1/4-28	AA184-428	IT-2528	\$4.00
5/16-18	AA184-518	IT-3118	\$4.00
5/16-24	AA184-524	IT-3124	\$4.00
3/8-16	AA184-616	IT-3716	\$4.00
3/8-24	AA184-624	IT-3724	\$4.00
M4	AA184-470	IT-470	\$4.00
M5	AA184-580	IT-580	\$4.00
M6	AA184-610	IT-610	\$4.00
M8	AA184-8125	IT-8125	\$4.00
M10	AA184-1015	IT-1015	\$4.00

Mandrels are for 1st grip range product only.
Contact Sherex for part numbers and pricing on
2nd grip range mandrels.

To Use:

- 1) Drill a hole into the material requiring the rivet nut.
- 2) Place bolt through the unthreaded nut with the smooth side of the nut in contact with the head of the bolt.
- 3) Thread rivet nut onto the bolt until the head of the rivet nut comes in contact with the knurled side of the unthreaded nut.
- 4) Place rivet nut into the hole.
- 5) Position two wrenches on the nut and the bolt head. Turn bolt clockwise causing the rivet nut to collapse and install in the base material.
- 6) Tighten until rivet nut cannot be installed further.
- 7) Remove bolt from rivet nut.
- 8) Attach component.

MADE IN THE USA!