


8804541  
motor cover



302-E  
39062

| Re-Order# | P/N | Description                       | Re-Order# | P/N | Description                      |
|-----------|-----|-----------------------------------|-----------|-----|----------------------------------|
| 88001     | 1   | Safety valve                      | 88045     | 45  | Valve body o' ring               |
| 88002     | 2   | Body cover                        | 88046     | 46  | Valve piston                     |
| 88003     | 3   | Frame head o' ring                | 88047     | 47  | Valve piston o' ring             |
| 88004     | 4   | Screw stem                        | 88048     | 48  | O' rings (x4)                    |
| 88005     | 5   | Air piston o' ring                | 88049     | 49  | Vacuum adjustment knob           |
| 88006     | 6   | Air piston                        | 88050     | 50  | Frame                            |
| 88007     | 7   | Piston washer                     | 88054     | 54  | Internal frame cylinder          |
| 88008     | 8   | Air piston rod                    | 85378     | 55  | 3/16 nosepiece (shown installed) |
| 88009     | 9   | Air piston stop                   | 88056     | 56  | Frame head                       |
| 88010     | 10  | Lower air piston guide o' ring    | 88057     | 57  | Front jaw case                   |
| 88011     | 11  | Internal air piston guide o' ring | 85387     | 58  | Jaws (x3)                        |
| 88012     | 12  | Air piston guide connector        | 88059     | 59  | Jaw piston                       |
| 88013     | 13  | Air piston gasket                 | 88060     | 60  | Mandrel container                |
| 88014     | 14  | Air piston guide                  | 88061     | 61  | Vacuum tube                      |
| 88015     | 15  | Upper air piston guide o' ring    | 88062     | 62  | Jaw case o' ring                 |
| 88016     | 16  | Retainer ring                     | 88063     | 63  | Rear jaw case                    |
| 88017     | 17  | Retaining ring                    | 88064     | 64  | Vacuum tube extension            |
| 88018     | 18  | Valve plug o' ring (x2)           | 88065     | 65  | Balance connection               |
| 88019     | 19  | Valve plug                        | 88066     | 66  | Gasket sleeve o' ring            |
| 88020     | 20  | Retainer ring                     | 88067     | 67  | Gasket sleeve                    |
| 88021     | 21  | Outer valve piston o' ring        | 88068     | 68  | Sleeve gasket                    |
| 88024     | 24  | Coil/Frame o' ring (x2)           | 88069     | 69  | Washer                           |
| 88025     | 25  | Coil                              | 88070     | 70  | Retaining ring                   |
| 88026     | 26  | Spring coil (x2)                  | 88071     | 71  | Gasket stop ring                 |
| 88027     | 27  | Cage (x3)                         | 88072     | 72  | Oil piston gasket                |
| 88028     | 28  | Cage o' ring (x3)                 | 88073     | 73  | Oil piston gasket ring           |
| 88029     | 29  | Valve spacer                      | 88074     | 74  | Oil piston                       |
| 88031     | 31  | Air cylinder                      | 88075     | 75  | Interior piston spring           |
| 88032     | 32  | Internal air piston o' ring       | 88076     | 76  | Exterior piston spring           |
| 88033     | 33  | Silencer                          | 88077     | 77  | Spring guide plug                |
| 88034     | 34  | Fluid plug washer                 | 88078     | 78  | Mandrel container connector      |
| 88035     | 35  | Fluid plug                        | 85375     | 79  | 3 / 32 Nosepiece                 |
| 88038     | 38  | Connector                         | 85376     | 80  | 1 / 8 Nosepiece                  |
| 88041     | 41  | Output connector                  | 85377     | 81  | 5 / 32 Nosepiece                 |
| 88042     | 42  | Push button                       | 85379     | 82  | 1 / 4 Nosepiece                  |
| 88043     | 43  | Trigger o' ring                   | 88220-22  | 87  | Air conveyor                     |
| 88044     | 44  | Valve body                        | 88220-45  | 88  | Hex connector                    |
|           |     |                                   | 88089     | 89  | Bushing o' ring                  |
|           |     |                                   | 88090     | 90  | Bushing                          |
|           |     |                                   | 88095     | 95  | Retaining ring                   |
|           |     |                                   | 88096     | 96  | Rubber boot                      |
|           |     |                                   | 712162    | 97  | Silencer shield                  |
|           |     |                                   | 88098     | 98  | Cylinder tube                    |
|           |     |                                   | 88030     | 99  | Washer stop spring               |
|           |     |                                   | 88100     | 100 |                                  |