


NOTES:

- 1 REMOVE PINTAIL EJECTOR FROM TOOL, AND INSTALL PINTAIL EJECTOR 104280
- 2 ASSEMBLE NOSE ASSY TO TOOL PER HUCK SPEC 42-297
- 3 COLLET AND LOCK ASSEMBLY 128219 CONSISTS OF:
128220 COLLET (NOT AVAILABLE SEPERATELY)
128221 RELEASE
128225 EJECTOR
101282 LOCK ASSEMBLY
- 4 SHIP WITH SPLIT RING ASSEMBLY 104643 CONSISTING OF:
100455 SPLIT RING SET
100456 SLEEVE

REV	DESCRIPTION	DATE
A	RELEASE	07/11/06



11	101282	1	LOCK ASSEMBLY
10	104280	1	PINTAIL EJECTOR
9	501018	1	RETAINING RING
8	128224	1	SPRING SEAT
7	508290	1	SPRING
6	128222	1	FOLLOWER
5	104256	1	JAWS
4	128221	1	RELEASE
3	128220	1	COLLET
2	128225	1	EJECTOR
1	128218	1	ANVIL
ITEM	PART NO.	QTY.	DESCRIPTION

HUCK INTERNATIONAL, INC. I.S.D.
1 CORPORATE DR. P.O. BOX 2270
KINGSTON, NEW YORK 12401

NOSE ASSEMBLY
-18 CSOL. SPECIAL

REV: N06 00 07/11/06 211

FOC. B 99-5022

★ IDENTIFICATION PER SPEC 42-311: ETCH