





AIR MOTOR



FLEX-5P SPARE PARTS

Ref.	Sherex Part Number	Description	Qty.	Ref.	Sherex Part Number	Description	Qty.
1	FLEX5-12091	NOSE CASE	1	33	FLEX5-12008	SEAL	1
2	FLEX5-12092	ADAPTOR NUT	1	34	FLEX5-03020	PISTON	1
3	FLEX5-K6842	JOINT KIT	1	35	FLEX5-12002	RUBBER BASE	1
4	FLEX5-12044	SPINDLE	1	36	FLEX5-12036	ELASTIC RING	1
5	FLEX5-00803	NUT	1	37	FLEX5-03023	O RING	1
6	FLEX5-12056	PISTON ROD	1	38	FLEX5-00038	PLATE	1
7	FLEX5-02004	SEAL	1	39	FLEX5-00039	PIN	1
8	FLEX5-12053	SEAL	1	40	FLEX5-K4040	O RING KIT 4 pcs	1
9	FLEX5-12121	O RING	1	41	FLEX5-K1741	PRESSURE KIT 17 pcs	1
10	FLEX5-12014	OIL PISTON	1	42	FLEX5-K7042	SEALS KIT + O RING 7 pcs	1
11	FLEX5-12015	SPRING	1	43	FLEX5-K2043	SPRINGS KIT 2 pcs	1
12	FLEX5-P0012	RING NUT	1	44	FLEX5-K4044	O RING KIT 4 pcs	1
13	FLEX5-03014	SCREW	2	45	FLEX5-K0045	TRIGGER KIT + O RING	1
14	FLEX5-P0014	MOTOR COVER	1	46	FLEX5-00046	TRIGGER	1
15	FLEX5-12078	PUSHING ROD	1	47	FLEX5-00047	PIN	1
16	FLEX5-00026	O RING	1	48	FLEX5-03013	AIR CYLINDER	1
17	FLEX5-12079	BALL	1	49	FLEX5-12024	AIR MOTOR BODY	1
18	FLEX5-12027	DISTRIBUTOR	1			AIR MOTOR PARTS	
19	FLEX5-12007	SCREW	2	1A	FLEX5-12063	PLANET GEAR SPINDLE	1
20	FLEX5-03022	O RING	2	2A	FLEX5-09208	PLANET GEAR	3
21	FLEX5-12060	O RING	4	3A	FLEX5-12066	SPACER	1
22	FLEX5-03009	AIR TUBE	2	4A	FLEX5-09210	FRONT WASHER	1
23	FLEX5-01274	OIL PLUG	1	5A	FLEX5-09211	STATOR	1
24	FLEX5-03015	OIL SEAL	1	6A	FLEX5-09213	ROTOR BLADE	5
25	FLEX5-12037	HANDLE	1	7A	FLEX5-09216	PLUG	1
26	FLEX5-K8026	MANUAL REVERSE KIT 8 pcs	1	8A	FLEX5-12061	SEEGER	1
27	FLEX5-K5027	O RING KIT 5 pcs	1	9A	FLEX5-12062	BEARING	1
28	FLEX5-K5028	ROD GUIDE KIT 5 pcs	1	10A	FLEX5-12065	CROWN	1
29	FLEX5-K3029	SEAL KIT 3 pcs	1	11A	FLEX5-09206	BEARING	1
30	FLEX5-K0030	SWIVEL AIR KIT	1	12A	FLEX5-12070	ROTOR	1
31	FLEX5-00205	SPRING	1	13A	FLEX5-09214	BACK WASHER	1
32	FLEX5-03018	ROD	1	14A	FLEX5-09215	BEARING	1