




PARTS LIST

PRH840

Part Number	Description	Number Required
PRH 840-T	Medium Duty Corner Head	1
PRG 402-8A	Jaw	2
PRG 510-122	Retaining Ring	1
PRG 520-33	Jaw Pusher	1
PRN	Nosepiece	1
PRH 840-1	Housing	1
PRH 840-2	Nose Housing	1
PRH 840-3	Pulling Head Adaptor	1

Part Number	Description	Number Required
PRH 840-6	Bell Crank Bushing	2
PRH 840-7	Bell Crank	2
PRH 840-8	Bell Crank Fulcrum	1
PRH 840-9	Bell Crank Spacer	1
PRH 840-11	Jaw Guide	1
PRH 840-12	Jaw Pusher Spring	1
PRH840-25	Housing Cover	1
PRH840-26	Housing Cover Screw	2
PRH840-27	Cover Screw Spacer	2