


Chapter- 4


Pulling Head
Ass'y

Hydraulic Piston
Ass'y




Apply Loctite242 on the thread part
of Pulling Head Ass'y.

Pulling Head
Ass'y



Screw Pulling Head Ass'y to Hydraulic Piston Ass'y

Pulling Head
Ass'y



Memo
